




B'MOOV SATELLITE OBU








UNIT OPERATIONAL

| Unit | Meaning of LEDs and beeps |
|--|---|
|  | <p>The status and network LEDs are green Your unit is operational</p> <p>If your unit sounds 1 or 2 beeps, you can carry on driving</p> |

| Unit | Meaning of LEDs and beeps | What to do |
|---|--|--|
|  | <p>The message LED is white You have a message</p> | <p>Read your messages the next time you stop</p> |















OTHER CASES: the driver is potentially liable to pay fines

| Unit | LED meaning | What to do |
|--|---|--|
|  | <p>The status LED is green and flashing The unit has detected a temporary problem</p> | <p>Stop the vehicle Read the message on the screen and refer to the error codes on the next page</p> |
|  | <p>The network LED is orange You do not have an Axxès contract for the network you are driving on</p> | |
|  | <p>The technical and network LEDs are red and constant The unit is no longer operational</p> | <p>Stop the vehicle Call +33 (0)4 24 29 75 80</p> |
|  | <p>No LEDs are lit, or a single LED is lit Your unit is not operational</p> | <p>Stop the vehicle Plug the unit back in If the problem continues, call +33 (0)4 24 29 75 80</p> |

| Unit | Meaning of the beeps | What to do |
|--|--|---|
|  | <p>If your unit never beeps or beeps 4 times in a row, the unit is not operational</p> | <p>Stop the vehicle Call +33 (0)4 24 29 75 80</p> |

UNDERSTANDING THE UNIT

B'MOOV SATELLITE OBU

| Unit | Meaning of LEDs and beeps | What to do |
|---|--|---|
|   | The unit has detected a power supply problem | Stop the vehicle Check the power supply to your unit |
|   | The unit has detected a temporary problem | Stop the vehicle The problem continues for more than 15 min Call +33 (0)4 24 29 75 80 |
|   | | |
|   | The unit detects that you do not have an Axxès contract for the network you are driving on | You can subscribe to this network with Axxès: call +33 (0)4 26 29 75 20 |
|   | | |
|   | The unit does not detect an electric power supply Your unit is no longer operational | Stop the vehicle and check the power supply to your unit If the problem continues, call +33 (0)4 24 29 75 80 |
|   | Your unit is not operational | Stop the vehicle Note the error code and the message Call +33 (0)4 24 29 75 80 and report them |

